



INTEGRATED CONTROLLER

Protocol Manual

Rev. B



DUAL CAMERA QPT-50, QPT-90, & QPT-90 MARINE

WITH PTCR-95 STEPPER DRIVE

PTCR-95 Embedded Controller Protocol Rev B

02/23/06

Table of Contents

1. PAN & TILT COMMUNICATIONS PROTOCOL OVERVIEW:	2
1.1 AUTOBAUD:	2
1.2 STORAGE OF COORDINATE INFORMATION:	2
1.3 CAMERA AND LENS CONTROL:	3
1.4 GENERAL COMMUNICATIONS STRUCTURE:	4
1.5 CONTROL CHARACTERS:	4
1.6 CALCULATING THE CHECKSUM:	4
1.7 PASSING DATA THAT MATCHES CONTROL CHARACTER VALUES (ESC/BIT-7 SET):	5
1.8 PASSING INTEGER VALUES:	5
1.9 THE PROGRAMMER'S RESPONSIBILITY FOR INPUT RANGE AND FORMAT:	5
1.10 STATUS DEFINITIONS:	5
2. PTCR COMMAND SET:	6
2.1 NUMERIC COMMAND LIST:	6
2.2 "GET STATUS/JOG" & "KEEP ALIVE" COMMAND:	6
2.3 AUTOMATED "MOVE TO" COMMANDS:	8
2.3.1 "Move To Preset" Command:	8
2.3.2 "Move To Entered Coordinate" Command:	10
2.3.3 "Move To Delta Coordinates" Command:	10
2.3.4 "Move To Absolute 0/0" Command:	11
2.3.5 "Move To Home" Command:	11
2.4 THE PRESET TABLE:	13
2.4.1 "Retrieve Preset Table Entry" Command:	13
2.4.2 "Save Coordinates As Preset Table Entry" Command:	14
2.4.3 "Save Current Position As Preset Table Entry" Command:	14
2.4.4 "Save Current Zoom/Focus Positions To Preset Table Entry" Command:	15
2.5 THE PRESET TOUR:	15
2.5.1 "Start Preset Tour" Command:	16
2.5.2 "Flush Preset Tour" Command:	16
2.5.3 "Query Preset Tour" Command:	17
2.5.4 "Append To Preset Tour" Command:	17
2.5.5 "Insert Into Preset Tour" Command:	18
2.5.6 "Delete From Preset Tour" Command:	18
2.5.7 "Replace In Preset Tour" Command:	19
2.5.8 "Get Tour Size" Command:	19
2.6 CAMERA/LENS PARAMETERS AND CONTROL:	19
2.6.1 "Get/Set Camera Comm Parameters" Command:	20
2.6.2 "Get/Set Lens Parameters" Command:	20
2.6.3 "Command Camera" Command:	21
2.6.4 "Get/Set Camera Select/Power/Video" Command:	23
2.6.5 "Get/Set Camera Response Timeout" Command:	23
2.6.6 "Get/Set Aux Control Outputs" Command:	24
2.7 PTCR OPERATING PARAMETERS:	24
2.7.1 Setting Pan & Tilt Angle Corrections:	25
2.7.2 "Get Pan & Tilt Angle Correction" Command:	25
2.7.3 "Set Pan & Tilt Angle Correction" Command:	25
2.7.4 "Align To Center" Command:	26
2.7.5 "Align To Coordinate" Command:	26
2.7.6 "Clear Angle Corrections" Command:	27
2.7.7 "Get/Set Pan & Tilt Soft Limits" Command:	27
2.8 PTCR INITIAL SETUP PARAMETERS:	28
2.8.1 Getting/Setting Pan & Tilt Potentiometer Center Position:	28

2.8.2	"Get Pan & Tilt Potentiometer/Encoder Center Position" Command:.....	28
2.8.3	"Set Pan & Tilt Potentiometer Center Position" Command:.....	30
2.8.4	"Get/Set Pan & Tilt Ramp Parameters" Command:.....	30
2.8.5	"Initialize Preset Table to 0/0" Command:	31
2.8.6	"Get/Set Motor and Potentiometer/Resolver Direction" Command:	32
2.8.7	"Get/Set Heater Configuration" Command:.....	32
2.8.8	"Get/Set Communication Timeout" Command:	33
2.8.9	Encoder Alignment and Tracking:.....	33
2.8.10	"Initial Encoder Align" Command:	34
2.8.11	"Perform Homing Cycle" Command:.....	34
2.8.12	"Get/Set Identity Address" Command:	35
3.	CODE EXAMPLES	36
4.	REVISION HISTORY:	38
4.1	REV A 07/08/05	38
4.2	REV B 02/23/06	38

1. Pan & Tilt Communications Protocol Overview:

The controller PCB mounted internal to the QPT-90 (PTCR-95) will be addressable via an dedicated RS-422, dedicated RS-232, or shared half- or full-duplex (2-wire/4-wire) RS-485 communications link provided by an attached remote host. The host will act as master and be responsible for initiating and maintaining communications with the PTCR. The PTCR will remain idle until the server sends a query/command. The PTCR will then parse the packet, check for integrity, and respond as required. The host should not send packets faster than 10 times per second and, once communications is established, should wait for a valid response from the PTCR prior to transmitting the next packet. This is especially important during the saving of non-volatile parameters, preset, and tour information.

1.1 Autobaud:

An automatic baud detection procedure (autobaud) has been implemented. Supported baud rates are 9600bps, 14.4kbps, 19.2kbps, 28.8kbps, 38.4kbps, and 57.6kbps. Structure is 8 data bits, 1 stop bit, and no parity. Autobaud synchronization will only occur on power up and will not adapt "on the fly." The baud rate will be retained as long as power is applied to the PTCR. However, to change baud rates, the user may power the PTCR down, change host baud rate, then power the unit back up to redetect.

Normally, the user should make a practice of sending "keep alive" Get Status/Jog commands periodically if communications is lost in order to resync the PTCR to the host, even without the autobaud feature. With autobaud the host must be able to transmit up to 125-150 bytes of data (worst case) without a response expected in order for the PTCR to properly determine the data rate. This equates to about 15 Get Status/Jog commands. With a refresh rate of 100ms a maximum of about 2 seconds is required to determine baud rate. Once baud rate is determined the PTCR will begin responding to the Get Status/Jog commands and the host software may then move on to actual operation. Note that units configured in a shared network can sync on packets destined for another unit.

1.2 Storage of Coordinate Information:

The PTCR tracks position using feedback from the precision potentiometers and/or incremental encoders connected to the pan & tilt axes. Potentiometers provide an absolute position reading. Incremental encoder counts are continuously stored in non-volatile memory and are corrected as required at each crossing of the index position. This provides a "pseudo" absolute position.

The feedback from the potentiometers is oversampled 128 times, then divided to produce a 13-bit position value ranging from 0-8191. The PTCR uses these values, referred to as "resolver units", directly to execute any automated movement commands. Resolver units are converted to angular values only for user display. Angular values supplied by the user are converted back to resolver units for both preset storage and automated movement. The advantage of using this method is increased accuracy and higher conversion speed during movement. If a

user supplies an angular input for an automated move the PTCR converts it only once to a resolver unit value, then may directly compare this integer value to current resolver unit readings.

Alternately, a unit may be fitted with incremental encoders on one or both axes. A running count is maintained, incremented, or decremented every 50 μ s according to the current state of the encoder. This value is then stored in non-volatile memory. The encoder also provides an index pulse once per revolution. When initially configured at the factory, this index point is equated to a resolver value relative to absolute center in pan and is stored in non-volatile EEPROM. The current running value stored in non-volatile memory is updated frequently and will provide high accuracy at power up. However, if the platform is physically moved or bumped off position when powered down, the encoder changes will be missed and current position accuracy will be compromised. Whenever the index point is crossed during movement the encoder count will be automatically corrected using the stored index value. Optionally, the user may also reset to maximum accuracy by performing a homing cycle. See command 9EH. This command will automatically move the platform to the index point, realign the encoder count, and then return the platform to its original but corrected position.

Use of resolver units internally does have an effect, however, on the structure of preset table entries and user-defined angular corrections. Presets are stored internally in absolute resolver units. The angular position for those presets is a calculated value derived from the conversion of resolver units to angles and any angular offsets defined by the user. Let us say, for example, that the user has not defined any angular offset. Therefore, the 0°/0° point for the platform will truly read 0°/0°. The user then defines a preset at +20° in pan and -10° in tilt. If the user moves to this preset, the angular reading returned will be +20°/-10°. The user then decides to redefine the 0°/0° position to return -10° in pan and 0° in tilt by entering a -10° pan correction. Though the physical 0°/0° position remains the same, the angular reading for this position will now be returned as -10°/0°. If the user then moves to the former +20°/-10° preset the platform will move to the same preset position but the angle returned will be +10°/-10°.

There is an important rationale behind this coordinate system. Many will use the angular readings of the platform to observe the relative position of different targets. For example, the user may find that one object resides at -30° pan/-10° tilt relative to a true 0°/0° point. A second object resides at +25° pan/-20° tilt relative to the 0°/0° point. The user moves back to the first object and uses the "Align Angles to Center" command. This will introduce a pan angle correction of +30° and a tilt correction of +10°, adjusting the returned angular reading for the first object to 0°/0°. If the user now moves to the second object the angular reading will be +55° pan/-10° tilt, the actual angular distance from the first object.

Therefore, presets will always reflect known physical positions of the platform. No matter how the pan and tilt angles are shifted, a preset position will remain valid and correct and a command to move to that position will still return the platform to it. Introducing angular corrections will do nothing more than change the returned angular position but will not change the actual physical position of a preset. Additionally, software limits will also show this shift. Since a software limit is designed to prohibit movement beyond a specific point relative to center, the actual position of the software limit will not change when an angular offset is set. Only the value returned will change.

1.3 Camera and Lens Control:

The PTCR actually contains three microcontrollers; the main microcontroller dedicated to controlling the pan & tilt unit and dual slave microcontrollers dedicated to camera and lens control. Several non-volatile parameters are set and stored for identifying the operation of the lens and for determining whether a camera has serial remote control capabilities and, if so, what the communications level, baud rate, number of data bits, and parity are. At start-up the main microcontroller sends these parameters to the slaves. This determines how the slaves interpret data and formats it for the camera and lens.

Lens control is straightforward. A slave microcontroller controls two proportional-speed bi-directional motor drivers. One driver controls the focus motor and the second controls the zoom motor. Lenses are fitted with potentiometers for positional feedback. The potentiometer output for each axis is connected to the slave microcontroller ADC's and is converted to a binary value indicating current position. This value is then returned to the host. The host may send a request to move the zoom and focus motors to an undetermined final position (jog) or a predetermined final position (move to.) These predetermined final positions are stored as part of the pan and tilt's preset table, allowing the system to move to specific pan and tilt coordinates while also adjusting zoom and focus on both cameras.

Camera control is more difficult due to the numerous control signals available for each camera type. Therefore, a special variable-length command 62H is used to wrap a complete camera command for transfer to the camera. The user should build a complete camera command string. It should then be prepended and appended with the appropriate PTCR control bytes for transfer to the main microcontroller. The main microcontroller will then strip the intact camera command out of the packet and transfer it to the slave microcontroller where it will then be sent to the camera. See command 62H, "Command Camera", below for more detail.

The PTCR can also return received camera data through the "Get Status/Jog" command and response. The PTCR indicates that a camera string is available by changing the "cam count" byte for a camera from 0 to the number of bytes returned. When the host sees this change the indicated number of bytes should be removed from the response and stored for camera response parsing. The PTCR will return the camera's data string verbatim, including all control characters, checksums, etc. See command 31H for more information.

1.4 General Communications Structure:

The general structure of the host-to-PTCR communications protocol is as follows:

Host	STX	Identity Address	Command Number	Data	Checksum	ETX
PTCR	ACK/NAK	Identity Address	Echoed Command Number	Data	Checksum	ETX

When operating in RS-485 daisy-chain mode the identity address is used to determine which of the connected pan and tilt units is being commanded and should respond. All others will ignore the command and remain quiet. This address is set using Command 9FH and can range from 00-99. Address 00 is reserved for dedicated RS-232 and RS-422 mode and for broadcast mode. When the 00 address is used it will be internally ignored and any attached PTCR will respond. The current PTCR identity will be returned as part of the standard responses. If the user needs to change the identity of a unit the 9FH identity command should be sent using the current identity as the identity address and the new identity as the data byte. The PTCR will return the current identity as its identity address and the new identity as its response. **From that point forward, the new identity will take effect.** If the user forgets the current identity it can always be set and retrieved using an identity address of 00. **However, all other platforms in the network must be disconnected before issuing ANY commands using address 00. Otherwise, all units will react to the command and seize the host receive line.**

The PTCR will always echo the last received command number back to the host in its response. Remote software can be configured to accept this echo as a confirmation that the command was actually received and will be responded to. In the command breakdowns that follow, the transmission from host to PTCR will always be followed by the response from PTCR to host.

1.5 Control Characters:

The following are definitions for control characters used in data transfer.

Char	Description	Sent By	Value
STX	Start of Text	Host	02H
ETX	End of Text	Host/PTCR	03H
ACK	Acknowledge	PTCR	06H
NAK	Not Acknowledge	PTCR	15H

1.6 Calculating the Checksum:

The checksum used for data transfer is a longitudinal redundancy check or LRC. It is calculated by XOR'ing bytes starting with the identity address and ending with the last data byte. The ACK/NAK/STX and ETX are **not** included in the LRC. The easiest method of calculating and comparing is to XOR all data bytes, then XOR the result with the LRC checksum. The result should be 0 (zero).

If a command string is received from the host, is parsed, and is found to have an incorrect checksum the PTCR will **not** respond. It is possible that the corruption occurred due to an improperly transmitted identity. Therefore, if the unit did respond it could collide with the return data from a properly addressed unit.

1.7 Passing Data that Matches Control Character Values (ESC/bit-7 Set):

When passing full 8-bit bitsets it is possible that a value may match a control character (ACK/NAK/STX/ETX.) Therefore, the protocol needs some method of distinguishing these values from control characters. The method used is the insertion of an ESC character prior to transmitting the conflicting data byte and the setting of Bit-7 of the conflicting byte. Since we must also be able to distinguish the ESC value of 1BH we will perform the same operation on ESC's.

Example: Data to send = 02H Data sent = 1BH 82H
 Data to send = 1BH Data sent = 1BH 9BH

This insertion should be performed on **any byte that is not a control character, including the LRC**. Note that this procedure should be performed immediately prior to transmission and the companion decoding should be performed prior to checksum calculation after reception. These insertions are not included in the LRC calculations. The entire receive buffer should be scanned prior to LRC check and parsed for any occurrences of ESC. The ESC should be tossed, the following byte should have Bit-7 cleared, then the buffer should be shifted down. The buffer will then be ready for LRC calculation and data parsing.

The inclusion of ESC sequences provides two distinct advantages. First, the user is assured that any reception of an ACK or ETX is valid. Unless an error occurs, these control characters will not show up as data bytes in the packet. Therefore, it is perfectly valid to cue the start of reception on any ACK character. It is also valid to cue the end of reception and begin parsing data on the reception of an ETX. Since the ACK and ETX are not used in the calculation of the LRC, the user can simply use them as starting and stopping cues. Secondly, unlike the original implementation of IBM bisync on which this protocol was based, the user is allowed to pass full 8-bit binary values. Code snippets are provided at the end of this document demonstrating different approaches in C for implementing LRC calculation, LRC checking, and ESC insertion and removal.

1.8 Passing Integer Values:

As noted in the protocol command descriptions, some values sent between the host and PTCR units are integer values. These integer values should be passed and received as 16-bit signed two's-complement little endian integers simply split between two bytes. The first byte should represent the LSB of the integer with the second byte containing the MSB of the integer. Negative values are represented as the two's-complement of the positive value. For example:

Integer Value	Integer in Hex	First Byte	Second Byte
32767	7FFFH	FFH	7FH
2	0002H	02H	00H
1	0001H	01H	00H
0	0000H	00H	00H
-1	FFFFH	FFH	FFH
-2	FFFEH	FEH	FFH
-32768	8000H	00H	80H

1.9 The Programmer's Responsibility for Input Range and Format

The microcontroller used for the PTCR has a relatively small amount of code space. Extensive range and format checking of all user input would seriously task the processor and limit the amount of space left for executable procedures. The listings for each command in this document present the allowable range for each byte or integer of data. The user/programmer is responsible for providing inputs that are properly formatted and within the specified numeric range for each command. However, **absolute coordinates, preset numbers and static tour step locations** are checked and flagged if out of range or otherwise invalid.

1.10 Status Definitions:

Bits are active high, i.e., "set" or "1" indicates the condition exists. (S)oft faults are self-healing. (H)ard faults require a RESET (RES) command to clear.

Sym	Type	Name	Description
xHL	S Fault	Hard Limit	An axis hard limit has been reached.

xSL	S Fault	Soft Limit	An axis soft limit has been reached.
TO	H Fault	Timeout	A commanded axis is not moved within the prescribed timeframe.
DE	H Fault	Direction Error	A commanded axis has moved in the wrong direction.
OL	H Fault	Current Overload	A commanded axis has tripped the current overload.
xRF	S Fault	Resolver Fault	A synchro-resolver is disconnected or not operating properly.
xxxM	Stat	Moving	The commanded axis is currently moving.
OSLR	Stat	Override Return	The controller is in soft limit override.
DES	Stat	Destination	The coordinates returned are destination coordinates, not current.
EXEC	Stat	Executing	The PTCR is executing a remote initiated command.
CON	Stat	Cont Rotation	Platform is continuous rotation. Pan soft/hard limits are ignored.

2. PTCR Command Set:

This section includes information on the actual commands used to control and monitor the pan & tilt unit and attached camera.

2.1 Numeric Command List:

Cmd	Name	Cmd	Name
31H	Get Status/Jog	63H	Get/Set Select Camera/Power/Video
32H	Move To Preset	65H	Get/Set Camera Timeouts
33H	Move To Entered Coordinates	66H	Get/Set Aux Control Outputs
34H	Move To Delta Coordinates		
35H	Move To Absolute 0/0	80H	Set Pan & Tilt Angle Correction
36H	Move To Home	81H	Get/Set Soft Limit
37H	Start Preset Tour	82H	Align Angles To Center
		83H	Align Angles To Coordinates
40H	Retrieve Preset Table Entry	84H	Clear Angle Correction
41H	Save Coordinates As Preset Table Entry	85H	Get Pan & Tilt Angle Correction
42H	Save Current Position As Preset Table Entry		
43H	Add Current Z/F To Preset Table Entry	90H	Get Center Position in RU's
		91H	Set Center Position
50H	Flush Preset Tour	92H	Get/Set Pan and Tilt Ramp Parameters
51H	Query Preset Tour	94H	Initialize Preset Table to 0/0
52H	Append To Preset Tour	95H	Get/Set Motor and Resolver Direction
53H	Insert Into Preset Tour	96H	Get/Set Communication Timeout
54H	Delete From Preset Tour	97H	Get/Set Heater Power Sharing
55H	Replace In Preset Tour	9DH	Initial Encoder Align
56H	Get Tour Size	9EH	Perform Homing Cycle
		9FH	Get/Set Identity Address
60H	Get/Set Camera Comm Parameters		
61H	Get/Set Lens Parameters		
62H	Command Selected Camera		

2.2 "Get Status/Jog" & "Keep Alive" Command

This command can be used as a standard "Keep Alive" from the host unit to continuously gather coordinate data. This command should be the one sent when no other command is required. This will keep the host advised of current position and any faults that may exist. This will also confirm to the PTCR that the host is connected and properly communicating.

The jog bytes contain both a direction and a speed value. This allows proportional, simultaneous jog control of both axes. Holding the speed value for an axis at 0 will prohibit jogging that axis. Setting the "SLO" bit will reduce jog speed by a factor of 64. Automated moves will still execute at normal speed. Note that any jog command that includes a speed value other than 0 will automatically stop any automated command. Therefore, initiating a jog can be used to terminate an automated move, including a preset tour. Four commands provide zoom and focus jog

control for both cameras. These commands embed both speed and direction for zoom and focus. Zoom and focus can be adjusted independently of pan & tilt jog.

The "STOP" bit can also be used to stop all motors during execution of an automated movement command. For example, if a "MOVE TO" is to be executed the host would send the "MOVE TO" command once, then return to the "GET STATUS/JOG" command to update position display. If the user wishes to stop the "MOVE TO" command from the host the "STOP" bit should be set then, after confirmation of reception, cleared. This will cause the PTCR to stop the motors, fall out of the "MOVE TO" procedure, and return to a state waiting for the next command.

The "RES" or reset bit is used to clear latching (hard) faults. These include motor directional errors (DE) and timeouts (TO). A timeout fault will be set if an axis fails to move within 1 second. This may be the result of a stalled motor or an overloaded platform. A directional error fault will be set if an axis is detected as moving in the wrong direction. This may be the result of improper motor wiring. **Note that the DE and TO faults will only occur during automated moves.** The user should observe the angular readings during jog to confirm motors are moving the proper direction and are not stalled. The "OSL" bit allows overriding soft limits during jog. **This bit should only be set when initially setting up the soft limits.** Its current setting will be returned in the OSLR bit.

Though actual movement in pan and tilt is restricted to $\pm 180^\circ$ and $\pm 90^\circ$ respectively, a figure of double this amount may be returned by a status query. This is allowed to accommodate any angular offsets that may be set by the user.

Since camera response data can be embedded in the status response, the response packet is variable length. The user should cue on the reception of a valid ETX to end the packet. If the platform has no camera response data to return the camera byte counts will be 0. However, if they are greater than 0, the host should read the additional bytes when parsing the packet. Note that the camera byte count reflects the actual length of the camera response and does not include a count of any ESC characters that may have been inserted to keep the return data from conflicting with any control characters.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Cmd Num	31H	1								
Cmd	Bitset	1	0	0	0	SLO	RU	OSL	STOP	RES
Pan Jog Cmd	Bitset	1	Pan Speed (0-127)							Dir ¹
Tilt Jog Cmd	Bitset	1	Tilt Speed (0-127)							Dir ²
Zoom 1 Jog	Bitset	1	Zoom Speed (0-127)							Dir ³
Focus 1 Jog	Bitset	1	Focus Speed (0-127)							Dir ⁴
Zoom 2 Jog	Bitset	1	Zoom Speed (0-127)							Dir ³
Focus 2 Jog	Bitset	1	Focus Speed (0-127)							Dir ⁴
LRC	xxH	1								
ETX	03H	1								

¹1 = CW/0 = CCW 0 Speed = No Movement

²1 = UP/0 = DWN 0 Speed = No Movement

³1 = Zoom Out/0 = Zoom In 0 Speed = No Movement

⁴1 = Focus Out/0 = Focus In 0 Speed = No Movement

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Cmd Num	31H	1								
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°							
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°							
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF
TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON ²	EXEC	DES ¹	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1	1-255							
Focus 1 Pos	Byte	1	1-255							

Zoom 2 Pos	Byte	1	1-255
Focus 2 Pos	Byte	1	1-255
Cam 1 Count	Byte	1	0-80 for number of bytes of camera data to follow
Cam 2 Count	Byte	1	0-80 for number of bytes of camera data to follow
Cam 1 Data	Bytes	0-80	Camera return string in native format (only present if Cam Count 1 > 0)
Cam 2 Data	Bytes	0-80	Camera return string in native format (only present if Cam Count 2 > 0)
LRC	xxH	1	
ETX	03H	1	

¹DES bit is clear if coordinates are current, set if coordinates are the destination of a MOVE TO command.

²Indicates the platform is continuous rotation. Pan soft/hard limits should be ignored.

2.3 Automated "Move To" Commands:

Any "Move To" command should only be repeated until an acknowledgement has been received from the PTCR (echo of the command number). The host should then revert back to the standard 31H "Get Status/Jog" query. The PTCR will set the EXEC (executing) bit in the general status bitset to indicate that the command is being carried out. This bit will clear once the move has been completed.

The PTCR response to any automated "Move To" command will be identical to the standard status response with one exception. The response will echo the destination coordinates either as entered or retrieved from the preset table rather than the current coordinates. The setting of the destination bit DES, bit-5 of general status will indicate this. Status will then default back to current coordinates once the "Get Status/Jog" command/response resumes and the DES bit clears. The user may cue on the DES bit in order to fill a "Moving To" window with the destination coordinates. If the PTCR is detecting hard faults that will prohibit executing a "Move To" command it will echo the current position as the destination coordinates. This should act as a reminder for the user to check the fault status.

Movement will start once the PTCR has parsed the "Move To" coordinates. The setting of the appropriate axis MOVE bits in the status response will indicate this. As each axis arrives on station the respective MOVE bit will be cleared. The host may assume the move has been completed when all MOVE bits and the EXEC bit have cleared. If a fault occurs on **any** axis **all** motors will stop. The fault will be set and all MOVE bits and the EXEC bit will clear.

Setting the STOP bit or setting jog speed to a value other than 0 in any following "Get Status/Jog" command will immediately terminate any automated "Move To" operation. Sending any command other than the 31H "Get Status/Jog" command during an automated move will also terminate the automated "Move To" command.

2.3.1 "Move To Preset" Command:

The PTCR can retain up to 32 position entries in a non-volatile table that are frequently used by the operator. This command is used to move the platform to a preset position defined in this preset table. Further information on setting up the preset table is provided under command 40H below. If a preset number greater than 31 is entered no move will occur.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	32H	1	
Preset	xxH	1	Preset Number 0-31
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	32H	1								
PAN Coord	Int	2								
TILT Coord	Int	2								
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF

TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON	EXEC	1	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1	1-255							
Focus 1 Pos	Byte	1	1-255							
Zoom 2 Pos	Byte	1	1-255							
Focus 2 Pos	Byte	1	1-255							
LRC	xxH	1								
ETX	03H	1								

2.3.2 “Move To Entered Coordinate” Command:

This command is used to move the platform to a specific set of manually entered coordinates. The coordinate must consist of the desired position to 1/10th degree multiplied by 10, i.e., +90.0° should be sent as 900. The user can force an axis to remain in position by sending its current position back to the PTCR. However, the coordinate value 9999 (+999.9°) can also be sent in order to prohibit movement of a specific axis. For example, if the user wishes to only move PAN, send 9999 (+999.9°) as the “Move To” coordinate for TILT and the TILT axis will remain stationary.

The PTCR will perform a range check for the input coordinates and abort the move if a coordinate is out of range. Allowable pan range is defined as -180.0° + pan angle offset to +180.0° + pan angle offset.

Allowable tilt range is -90.0° + tilt angle offset to +90.0° + tilt angle offset. For an angle offset of 0°/0°, the range would be -180.0°/+180.0° and -90.0°/+90.0°. If a pan angle correction of +90.0° is entered, the allowable pan angle range would shift to -90.0° to 270.0°. If a tilt angle correction of -20.0° is entered, the allowable tilt angle range would shift to -110.0° to 70.0°.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	33H	1	
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0° or 9999 for no move
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0° or 9999 for no move
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	33H	1								
PAN Coord	Int	2								
TILT Coord	Int	2								
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF
TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON	EXEC	1	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1								1-255
Focus 1 Pos	Byte	1								1-255
Zoom 2 Pos	Byte	1								1-255
Focus 2 Pos	Byte	1								1-255
LRC	xxH	1								
ETX	03H	1								

2.3.3 “Move To Delta Coordinates” Command:

As opposed to moving to specific coordinates, the "Move To Delta Coordinate" command allows the user to move the platform a specific angular distance from the current position. The coordinate must consist of the desired position to 1/10th degree multiplied by 10, i.e., -20.0° should be sent as -200. The user can force an axis to remain stationary by sending 0 to the PTCR for that axis.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	34H	1	
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	34H	1								
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°							
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°							
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF
TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON	EXEC	1	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1	1-255							
Focus 1 Pos	Byte	1	1-255							
Zoom 2 Pos	Byte	1	1-255							
Focus 2 Pos	Byte	1	1-255							
LRC	xxH	1								
ETX	03H	1								

2.3.4 “Move To Absolute 0/0” Command:

The pan & tilt unit potentiometer/encoder resolvers are initially aligned with the platform centered and level. This command will return the platform to that stored center position. This is a convenient method for returning the platform to factory center for maintenance or hard limit switch alignment.

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	35H	1
LRC	XxH	1
ETX	03H	1

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	35H	1								
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°							
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°							
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF
TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON	EXEC	1	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1	1-255							
Focus 1 Pos	Byte	1	1-255							
Zoom 2 Pos	Byte	1	1-255							
Focus 2 Pos	Byte	1	1-255							
LRC	xxH	1								
ETX	03H	1								

2.3.5 “Move To Home” Command:

A special preset position number 31, referred to as "Home", may be entered and stored by the PTCR. This command requires no preset number or coordinate input and will always return the pan and tilt unit to this "Home" position.

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	36H	1
LRC	XxH	1

ETX	03H	1
-----	-----	---

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	36H	1								
PAN Coord	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°							
TILT Coord	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°							
PAN Status	Bitset	1	CWSL	CCWSL	CWHL	CCWHL	TO	DE	OL	PRF
TILT Status	Bitset	1	USL	DSL	UHL	DHL	TO	DE	OL	TRF
Gen Status	Bitset	1	CON	EXEC	1	OSLR	CWM	CCWM	UPM	DWNM
Zoom 1 Pos	Byte	1	1-255							
Focus 1 Pos	Byte	1	1-255							
Zoom 2 Pos	Byte	1	1-255							
Focus 2 Pos	Byte	1	1-255							
LRC	xxH	1								
ETX	03H	1								

2.4 The Preset Table:

The PTCR can retain up to 32 (0-31) preset positions in non-volatile memory that are frequently used by the operator. The user can store, retrieve, or move to these coordinates by modifying and using the preset table as outlined below. Preset zoom and focus positions can also be stored.

A special preset, referred to as "Home" position, can be directly driven to without referencing a preset number using command 36H. It should be saved at preset position 31. This position can also be assigned as a generic preset and can be included in a preset tour.

Any command to store or retrieve a preset entry will echo back the preset's coordinates. If a preset number greater than 31 is entered the preset number will be echoed as FFH and the remainder of the data will be 0's.

2.4.1 "Retrieve Preset Table Entry" Command:

The operator may retrieve the stored coordinate position and zoom/focus byte values for any preset.

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	40H	1
Preset Num	xxH	1
LRC	XxH	1
ETX	03H	1

Data	Format	Bytes
ACK	06H	1
Identity	xxH	1
Command	40H	1
Preset Num	xxH	1
Preset Pan	Int	2
Preset Tilt	Int	2
Zoom 1	xxH	1
Focus 1	xxH	1
Zoom 2	xxH	1
Focus 2	xxH	1
LRC	xxH	1
ETX	03H	1

2.4.2 “Save Coordinates As Preset Table Entry” Command:

This command allows the user to load a specific set of coordinates to the preset table. The PTCR will perform a range check for the input coordinates and abort saving if a coordinate is out of range. Allowable pan range is defined as $-180.0^{\circ} + \text{pan angle offset}$ to $+180.0^{\circ} + \text{pan angle offset}$. Allowable tilt range is $-90.0^{\circ} + \text{tilt angle offset}$ to $+90.0^{\circ} + \text{tilt angle offset}$. For an angle offset of $0^{\circ}/0^{\circ}$, the range would be $-180.0^{\circ}/+180.0^{\circ}$ and $-90.0^{\circ}/+90.0^{\circ}$. The user may save coordinates that exceed both soft and hard limits. Zoom and focus settings cannot be arbitrarily entered and should be determined by actually zooming and focusing the cameras using jog. Commands 42H and 43H below will allow storage of zoom and focus settings. **Note that this command will take approximately 100ms to complete.**

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	41H	1	
Preset Num	xxH	1	0-31 (0-1FH)
Preset Pan	Int	2	PAN = -3600 to +3600 = -360.0° to $+360.0^{\circ}$
Preset Tilt	Int	2	TILT = -1800 to +1800 = -180.0° to $+180.0^{\circ}$
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	41H	1	
Preset Num	xxH	1	0-31 (0-1FH) or FFH if preset out of range
Preset Pan	Int	2	PAN = -3600 to +3600 = -360.0° to $+360.0^{\circ}$
Preset Tilt	Int	2	TILT = -1800 to +1800 = -180.0° to $+180.0^{\circ}$
Zoom 1	xxH	1	1-255 (01H-FFH)
Focus 1	xxH	1	1-255 (01H-FFH)
Zoom 2	xxH	1	1-255 (01H-FFH)
Focus 2	xxH	1	1-255 (01H-FFH)
LRC	xxH	1	
ETX	03H	1	

2.4.3 “Save Current Position As Preset Table Entry” Command:

This command allows the user to store the platform's current position and zoom/focus settings as a preset table entry. **Note that this command will take approximately 100ms to complete.**

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	42H	1	
Preset Num	xxH	1	0-31 (0-1FH)
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	42H	1	
Preset Num	xxH	1	0-31 (0-1FH) or FFH if preset out of range
Preset Pan	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°
Preset Tilt	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°
Zoom 1	xxH	1	1-255 (01H-FFH)
Focus 1	xxH	1	1-255 (01H-FFH)
Zoom 2	xxH	1	1-255 (01H-FFH)
Focus 2	xxH	1	1-255 (01H-FFH)
LRC	xxH	1	
ETX	03H	1	

2.4.4 “Save Current Zoom/Focus Positions To Preset Table Entry” Command:

This command allows the user to append the platform's current zoom and focus positions to an existing preset table entry. This allows the user to set a pan & tilt preset, manually jog the lenses until zoom and focus is set, then add the valid zoom and focus positions to the preset. **Note that this command will take approximately 100ms to complete.**

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	43H	1	
Preset Num	xxH	1	0-31 (0-1FH)
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	43H	1	
Preset Num	xxH	1	0-31 (0-1FH) or FFH if preset out of range
Preset Pan	Int	2	PAN = -3600 to +3600 = -360.0° to +360.0°
Preset Tilt	Int	2	TILT = -1800 to +1800 = -180.0° to +180.0°
Zoom 1	xxH	1	1-255 (01H-FFH)
Focus 1	xxH	1	1-255 (01H-FFH)
Zoom 2	xxH	1	1-255 (01H-FFH)
Focus 2	xxH	1	1-255 (01H-FFH)
LRC	xxH	1	
ETX	03H	1	

2.5 The Preset Tour:

The PTCR can hold three 63-step (0-62) preset tours. Preset tours are built only from assigned presets and allow the pan and tilt unit to sequentially move to a preset in the tour, wait a defined period of time, move to the next preset in the tour, wait a defined period of time, etc. Optionally, the user may also switch video signals when the preset position is reached (see the CV1 and CV2 bits) and blank the returned video during execution of a step (see the VBL bit.) Tours will be continuously executed until a "STOP" or jog command is received or a command other than a status query is received. **If a fault occurs or a soft or hard limit is reached the tour will stop executing.**

Tours are built by first flushing the existing tour. This will reset the tour pointer to 0. The user then sequentially adds preset numbers (0-31) and wait times (0-99 secs) to each stop in the tour. Once built, the tour can be started using the "Start Preset Tour" command, selecting which tour to execute.

The user may query both the number of steps in a tour and an actual entry's values using the "Get Tour Size" and "Query Preset Tour" commands. The user also has the capability to edit the preset tour using the "Append To Preset Tour", "Insert Into Preset Tour", "Delete From Preset Tour", and "Replace In Preset Tour" commands. The first command simply adds a preset to the end of the tour. The second allows the user to insert a preset into the tour while retaining the presets that follow. The third allows the user to remove a preset while retaining the presets that follow. In both cases, the presets that follow will be shifted up or down as required to keep the tour complete. The fourth command allows the user to replace a tour entry without disturbing the remaining tour entries. Note that the special "Home" preset 31 can be included in a tour.

Note that, as each step begins execution, the PTCR will return a response similar to the standard "Get Status/Jog" response but with the DES bit set, indicating that the coordinates returned are the actual destination for the move.

2.5.1 "Start Preset Tour" Command:

This command allows the user to execute any one of the three preset tours. If the tour is empty FFH will be returned. See each type below for further tour information.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	37H	1	
Tour Num	xxH	1	0-2
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	37H	1								
Tour Num	xxH	1								
LRC	xxH	1								
ETX	03H	1								

2.5.2 "Flush Preset Tour" Command:

The operator may completely clear a tour and ready it for building by using this command. This command should also be used to clear a tour that is found to be corrupt.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	50H	1	
Tour Num	xxH	1	0-2
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	50H	1	
Tour Num	xxH	1	0-2
LRC	xxH	1	
ETX	03H	1	

2.5.3 “Query Preset Tour” Command:

The operator may examine the sequential steps of a tour by using this command. If the response returns FFH for the step number, the requested step does not exist in the tour.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	51H	1	
Tour Num	xxH	1	0-2
Step Num	xxH	1	0-62 (0-3EH)
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	51H	1								
Tour Num	xxH	1								
Step Num	xxH	1								
Preset Num	xxH	1	CV2 ¹	CV1 ¹						
Wait Time	xxH	1	VBL ²							
LRC	xxH	1								
ETX	03H	1								

¹0 = No Automatic Camera Switching, CV1 Set = Switch to Cam1 Video, CV2 Set = Switch to Cam2 Video

²0 = No Video Blanking Between Moves, 1 = Video Blanking Between Moves

2.5.4 “Append To Preset Tour” Command:

The operator may append a preset to the tour by using this command. The step number returned by the response represents the tour position where the preset was saved. If FFH is returned the tour is full and the preset was not accepted or the tour is corrupt.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1								
Command	52H	1								
Tour Num	xxH	1								
Preset Num	xxH	1	CV2	CV1						
Wait Time	xxH	1	VBL							
LRC	XxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	52H	1								
Tour Num	xxH	1								
Step Num	xxH	1								
Preset Num	xxH	1	CV2	CV1						
Wait Time	xxH	1	VBL							
LRC	xxH	1								
ETX	03H	1								

2.5.5 “Insert Into Preset Tour” Command:

The operator may insert a preset into the tour by using this command. Any steps that follow the insertion will be moved out one step. If a step number of FFH is returned the tour is full and the preset was not accepted. If the step number returned is less than the step number sent the step did not originally exist and the new entry was appended to the tour.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	53H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH)							
Preset Num	xxH	1	CV2	CV1	0-31 (0-1FH)					
Wait Time	xxH	1	VBL	0-99 (0-FFH) seconds						
LRC	XxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	53H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH) or FFH for all if the current tour is full							
Preset Num	xxH	1	CV2	CV1	0-31 (0-1FH)					
Wait Time	xxH	1	VBL	0-99 (0-FFH) seconds						
LRC	xxH	1								
ETX	03H	1								

2.5.6 “Delete From Preset Tour” Command:

The operator may delete a preset in the tour by using this command. Any steps that follow the deletion will be moved back one step. If a step number of FFH is returned the tour did not contain the step to be deleted.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	54H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH)							
LRC	XxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	54H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH) or FFH for all if the step does not exist							
LRC	xxH	1								
ETX	03H	1								

2.5.7 “Replace In Preset Tour” Command:

The operator may replace a preset in the tour by using this command. All other existing steps will be unaltered. If a step number of FFH is returned the tour did not contain the step to be replaced.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	55H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH)							
Preset Num	xxH	1	CV2	CV1	0-31 (0-1FH)					
Wait Time	xxH	1	VBL	0-99 (0-FFH) seconds						
LRC	XxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	55H	1								
Tour Num	xxH	1	0-2							
Step Num	xxH	1	0-62 (0-3EH) or FFH for all if the step does not exist							
Preset Num	xxH	1	CV2	CV1	0-31 (0-1FH)					
Wait Time	xxH	1	VBL	0-99 (0-FFH) seconds						
LRC	xxH	1								
ETX	03H	1								

2.5.8 “Get Tour Size” Command:

The operator can query a tour to find out the number of steps stored. If the tour is corrupt this procedure will return FFH or 255. This is a good method of determining if the tour is corrupt before attempting to modify it.

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	56H	1
Tour Num	xxH	1
LRC	XxH	1
ETX	03H	1

Data	Format	Bytes
ACK	06H	1
Identity	xxH	1
Command	56H	1
Tour Num	xxH	1
Step Count	xxH	1
LRC	xxH	1
ETX	03H	1

2.6 Camera/Lens Parameters and Control

The PTCR will act as a transparent conduit for camera commands. Any command destined for the camera should be completely built including any control characters and checksums. It should then be placed inside a pan & tilt command wrapper (see command 62H.) Up to 80 bytes may be sent in one string to the camera. The PTCR will be made aware of the camera's required serial parameters by the setting of its own non-volatile parameters (see command 60H.) The PTCR will use this data to configure a transceiver and UART and send the string to the camera.

The PTCR-95 provides communications with up to 2 cameras. However, this cannot be done simultaneously. The user must select the camera prior to sending a command string to it (see command 62H.) The user may also control camera input power and select which camera returns video output via command 63H.

Normally, the PTCR will respond to a command 31H status query with standard status data and camera byte counts of 0. When a serial byte is received from a camera a timer will be started and the PTCR will wait for additional bytes to arrive (see command 65H.) As each byte is received it will be placed in a queue and the timer will be restarted. Once the timer expires the PTCR assumes the camera response is complete. The PTCR will tack the byte count and returned camera data onto the end of the next status response. Therefore, if a camera byte count greater than 0 is received the application should remove the camera bytes and use them as required.

Though a bit convoluted, this allows the PTCR to be transparent, negating the need for code changes to accommodate different camera types. This will also allow cameras that only operate with allow dedicated RS-232 or RS-422 links to participate in an RS-485 party line environment. However, the onus of building proper camera commands and parsing received data resides with the programmer.

2.6.1 “Get/Set Camera Comm Parameters” Command:

These parameters define the serial communications parameters and levels for the attached cameras. To determine proper settings for these values reference specific camera data. These parameters should be checked first if a camera is not responding to commands. Sending “0” as the baud rate will disable use of the camera serial port. Setting the Query bit will instruct the PTCR to return the current values without changing them. The secondary microcontrollers will be loaded with the new values once the parameters are stored. **These parameters should be properly configured before physically connecting the cameras for the first time or changing camera serial port levels.**

Currently, **only 8 bits, no parity may be set and any other setting will be ignored.** However, hooks have been left in to accommodate different formats in the future. The transmitted values will be ignored when simply querying the PTCR. Therefore, they do not need to be included.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	60H	1								
Camera 1	xxH	1	Query	0	LVL ¹	0-3 Parity/Bits ²		0-7 baud ³		
Camera 2	xxH	1	0	0	LVL ¹	0-3 Parity/Bits ²		0-7 baud ³		
LRC	xxH	1								
ETX	03H	1								

¹Camera 1/2 0 = RS-232/1 = RS-422

²0 = 8/N, 1 = 7/N, 2 = 7/E, 3 = 7/O (Only 8/None currently supported)

³0 = Disable, 1 = 9.6, 2 = 14.4, 3 = 19.2, 4 = 28.8, 5 = 38.4, 6 = 57.6, 7 = 115.2

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	60H	1								
Camera 1	xxH	1	0	0	LVL	0-3 Parity/Bits		0-7 baud		
Camera 2	xxH	1	0	0	LVL	0-3 Parity/Bits		0-7 baud		
LRC	xxH	1								
ETX	03H	1								

2.6.2 “Get/Set Lens Parameters” Command:

Proper setting of these values allow the slave microcontrollers to know how the zoom and focus motors should be powered, if they are installed, and if the pot reading needs to be inverted. Setting the correct minimum speed value will keep the zoom and focus motors from stalling. Maximum speed is always considered the full speed available

from the motor driver. This parameter should be checked first if the zoom and focus functions are not working properly.

Setting the Query bit will instruct the PTCR to return the current value without changing it. Clearing the Query bit will actually load the new value into the EEPROM. The secondary microcontrollers will be loaded with the new values once the parameters are stored.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	61H	1								
Lens 1	Bitset	1	Query	¹ ZE	² ZR	³ ZI	⁴ FE	⁵ FR	⁶ FI	0
Lens 1 Z Min	xxH	1	0-255 (00H-FFH) minimum zoom speed							
Lens 1 F Min	xxH	1	0-255 (00H-FFH) minimum focus speed							
Lens 2	Bitset	1	0	ZE	ZR	ZI	FE	FR	FI	0
Lens 2 Z Min	xxH	1	0-255 (00H-FFH) minimum zoom speed							
Lens 2 F Min	xxH	1	0-255 (00H-FFH) minimum focus speed							
LRC	xxH	1								
ETX	03H	1								

¹1 = Enable the Zoom Function

²1 = Reverse the Zoom Motor's Normal Operation

³1 = Invert the Zoom Resolver Reading

⁴1 = Enable the Focus Motor

⁵1 = Reverse the Focus Motor's Normal Operation

⁶1 = Invert the Focus Resolver Reading

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	61H	1								
Lens 1	Bitset	1	0	ZE	ZR	ZI	FE	FR	FI	0
Lens 1 Z Min	xxH	1	0-255 (00H-FFH) minimum zoom speed							
Lens 1 F Min	xxH	1	0-255 (00H-FFH) minimum focus speed							
Lens 2	Bitset	1	0	ZE	ZR	ZI	FE	FR	FI	0
Lens 2 Z Min	xxH	1	0-255 (00H-FFH) minimum zoom speed							
Lens 2 F Min	xxH	1	0-255 (00H-FFH) minimum focus speed							
LRC	xxH	1								
ETX	03H	1								

2.6.3 "Command Camera" Command:

This command acts as a transfer wrapper around a camera-specific command. In order to use this command the user should build an entire camera command string including any extra bytes such as control and framing characters and checksums the camera needs for communications. The PTCR-required STX, identity and command number should be prepended to the front and the ETX and LRC should be appended to the end. If the standard method of transmitting other commands is used (ESC insertion) any conflicting values in the camera string will be automatically converted to "safe" values for transmission to the PTCR.

The main processor of the PTCR will strip the camera command string out of this command, return any altered control character values to their original value, and transfer the string to the slave processor. The slave processor will then transfer it to the camera via the serial port. Note that the camera command string can be variable length **but cannot exceed 80 bytes**.

The PTCR will respond to this command, indicating that it was received correctly. Any data the camera has to return will be sent through the "Get Status/Jog" 31H command. Reference it for more information on receiving returned data from the cameras. Normally, camera communications is half duplex, i.e., the user should wait for a

response before sending another camera command. Otherwise, a camera command string in the microcontroller buffer may be overwritten.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	62H	1								
Cam/Count	xxH	1	¹ CN	1 – 80 bytes to follow						
Camera Cmd	xxH	1-80	Complete Camera Command String							
LRC	xxH	1								
ETX	03H	1								

¹0 = Camera 1/1 = Camera 2

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	62H	1								
LRC	xxH	1								
ETX	03H	1								

2.6.4 “Get/Set Camera Select/Power/Video” Command:

This command performs configuration of the camera video selection and power on or off for each camera. If the baud parameters have not been initialized (see Command 60H) it is possible the serial line driver could connect an RS-232 level signal to a camera expecting an RS-422 level signal or vice versa. It is recommended that the cameras not be connected until these levels are set properly via Command 60H.

The PTCR maintains two configuration states, initialize and operating. The initialize state will be the default configuration used when the unit is first powered on. The operating state may then be changed as required without impacting the initial state. Setting the Query bit with the STOR bit clear will return the current operating configuration. Setting the Query bit with the STOR bit set will return the stored default configuration. If Query is clear and the STOR bit is set the configuration byte will be stored in EEPROM and will be the new default configuration at power-up. Clearing both the Query bit and the STOR bit will change the current configuration but the default configuration will not change.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	63H	1								
Data	xxH	1	Query	STOR	0	0	¹ C2	¹ C1	² CV2	² CV1
LRC	xxH	1								
ETX	03H	1								

¹1 = Power On/0 = Power Off for Cameras 1/2

²1 = Camera 1/2 Video Select or both 0 = Video Blanked

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	63H	1								
Data	xxH	1	0	STOR	0	0	C2	C1	CV2	CV1
LRC	xxH	1								
ETX	03H	1								

2.6.5 “Get/Set Camera Response Timeout” Command:

As stated above, once a byte of data is received from the camera, the slave microcontroller will wait for a predefined time for additional bytes to arrive before flagging the main processor to gather and return them. The timer will be restarted every time an additional byte arrives. This method will reduce the number of partial string

returns and parsing repeats for the host. However, different cameras will require differing amounts of time to complete their responses. This command allows adjusting the timeout/transfer data timer in multiples of 9ms for the 2 cameras.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	65H	1								
Timeout 1	xxH	1	Query	1 – 100 (* 9ms)						
Timeout 2	xxH	1	0	1 – 100 (* 9ms)						
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	65H	1								
Timeout 1	xxH	1	0	1 – 100 (* 9ms)						
Timeout 2	xxH	1	0	1 – 100 (* 9ms)						
LRC	xxH	1								
ETX	03H	1								

2.6.6 “Get/Set Aux Control Outputs” Command

Each camera interface connector provides two auxiliary control outputs. These may be used to activate wipers, lens washers, lights, etc. Each line provides a voltage set at the input voltage of the PTCR-95 and a switched return path. Maximum loading for these outputs is dictated by the capacity of the input power supply but should be restricted to 1.5 Amps each or less. The auxiliary lines are toggle on/toggle off and will remain in the mode set by the last 66H command. The lines will be off by default at power-up. Setting the Query bit will instruct the PTCR to return the current value without changing it. Clearing the Query bit will load the new value into the unit and activate the lines accordingly.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	66H	1								
Aux Bits	xxH	1	Query	0	0	0	AUX22	AUX21	AUX12	AUX11
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	66H	1								
Aux Bits	xxH	1	0	0	0	0	AUX22	AUX21	AUX12	AUX11
LRC	xxH	1								
ETX	03H	1								

¹1 = Output On/0 = Output Off for AUX(Camera Number)(Output Number)

2.7 PTCR Operating Parameters:

Most parameters may be queried from the PTCR. A reduced set of PTCR parameters may also be modified through the host interface.

2.7.1 Setting Pan & Tilt Angle Corrections:

The pan & tilt unit is internally calibrated to reflect an absolute relationship between the bottom mounting plate, the enclosure, and the tilt frame. However, the situation may arise where the user wishes to offset the degree display. This may be a result of mounting orientation or the desired method of measuring. To correct the reading, the user may provide an offset value for the displayed pan and tilt coordinates. Entry of a positive offset will simply increase the respective degree display. Negative will decrease the degree display. Internal orientation will not change, only the displayed angle.

Sometimes it is beneficial to correct coordinate display for the platform relative to your point of reference. This can be manually performed by calculating and entering pan and tilt angle offsets. However, the "Align to Center" and "Align to Coordinate" commands listed below can be used to allow the PTCR to perform these calculations for you.

Note that any change in pan and tilt offset will also modify the displayed position of presets, soft limits, etc. The relative angles will be correct, however. For example, assume a unit has a 0° tilt offset, the tilt frame is level at 0° and the preset will move it to -20°. Executing the preset move will move the tilt frame to -20°. If a +10° tilt offset is loaded a unit with a level tilt frame will display +10° and, after moving to the preset, -10° will be displayed. The unit has still moved 20° relative to center. Only the displayed angle has been altered to accommodate for the offset. **Therefore, it is recommended that any modification of pan & tilt angle offset be followed by a reloading of the preset table and soft limits if normally displayed in your application.**

2.7.2 "Get Pan & Tilt Angle Correction" Command:

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	85H	1
LRC	xxH	1
ETX	03H	1

1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast

Data	Format	Bytes
ACK	06H	1
Identity	xxH	1
Command	85H	1
Pan Offset	Int	2
Tilt Offset	Int	2
LRC	xxH	1
ETX	03H	1

PAN = -1800 to +1800 = -180.0° to +180.0°

TILT = -900 to +900 = -90.0° to +90.0°

2.7.3 "Set Pan & Tilt Angle Correction" Command:

This command allows manual entry of angle correction. The PTCR will check the input range of both pan and tilt angle corrections and will not save invalid entries.

Data	Format	Bytes
STX	02H	1
Identity	xxH	1
Command	80H	1
Pan Offset	Int	2
Tilt Offset	Int	2
LRC	xxH	1
ETX	03H	1

1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast

PAN = -1800 to +1800 = -180.0° to +180.0°

TILT = -900 to +900 = -90.0° to +90.0°

Data	Format	Bytes
ACK	06H	1
Identity	xxH	1
Command	80H	1

1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast

Pan Offset	Int	2	PAN = -1800 to +1800 = -180.0° to +180.0°
Tilt Offset	Int	2	TILT = -900 to +900 = -90.0° to +90.0°
LRC	xxH	1	
ETX	03H	1	

2.7.4 “Align To Center” Command:

"Align To Center" will automatically calculate the pan and tilt angle corrections required to realign the angular position display for the platform so that the current position is considered a center position displaying a pan and tilt angle of 0°. This command is useful if the user wishes to measure the relative angle between two objects. The user may jog to the first object then execute "Align To Center", changing the displayed angle to 0°/0°. Jogging to the next target will display the relative angle between the two objects.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	82H	1	
LRC	xxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	82H	1	
Pan Offset	Int	2	PAN = -1800 to +1800 = -180.0° to +180.0°
Tilt Offset	Int	2	TILT = -900 to +900 = -90.0° to +90.0°
LRC	xxH	1	
ETX	03H	1	

2.7.5 “Align To Coordinate” Command:

"Align To Coordinate" allows entry of the desired position to display. For example, the platform is mounted on a southeast line, is jogged due east, and currently reads -45.0° in pan. The user wants this reading to be +90.0° reflecting a compass point. The user may calculate and manually enter an offset using Command 80H. Alternately, the user can simply enter +90.0° for pan using this command and the offset will be automatically calculated and stored.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	83H	1	
PAN Coord	Int	2	PAN = -1800 to +1800 = -180.0° to +180.0°
TILT Coord	Int	2	TILT = -900 to +900 = -90.0° to +90.0°
LRC	XxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	83H	1	
Pan Offset	Int	2	PAN = -1800 to +1800 = -180.0° to +180.0°
Tilt Offset	Int	2	TILT = -900 to +900 = -90.0° to +90.0°
LRC	xxH	1	
ETX	03H	1	

2.7.6 “Clear Angle Corrections” Command:

This command will clear any angular corrections to zero, realigning the platform angular display to the true 0°/0° position.

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	84H	1	
LRC	xxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	84H	1	
Pan Offset	Int	2	PAN = 0
Tilt Offset	Int	2	TILT = 0
LRC	xxH	1	
ETX	03H	1	

2.7.7 “Get/Set Pan & Tilt Soft Limits” Command:

The PTCR can contain degree positions that, when exceeded, can stop platform travel. These values are referred to as software or soft limits. Soft limits act as redundant safety stops in addition to the hard limit switches. Soft limits are normally set just inside the hard limits, making the soft limit the primary stop and the hard limit the redundant stop.

Though it would be possible to allow setting the soft limits by entering coordinates through the remote interface this feature has not been included in the interests of safety. It is critical that the platform be observed while soft limits are being set in order to avoid collisions. If the user can physically jog to the soft limit point without hitting anything, it is a safe limit. Therefore, soft limits can only be set using a "move to and assign" method.

The user should jog the platform to the desired limit position, then send the command with the appropriate axis identified in order to set the soft limit. The user may override any existing soft limit by setting the OSL (Override Soft Limit) bit in the jog command. **This bit should only be used to assist in establishing soft limits.** The returned OSLR will show when this bit is set. Continuous rotation units will not observe soft limit settings and the values returned may be disregarded. Presence of the ENC bit in the “Get Status/Jog” response will cue the user that the attached unit is continuous rotation. Setting the Query bit will return the current value for an axis. Clearing the Query bit will actually store the position for the axis.

Note that any change in pan and tilt offset will also modify the displayed position of presets, soft limits, etc. The relative angles will be correct, however. Therefore, it is recommended that any modification of pan & tilt angle offset be followed by a reloading of the preset table and soft limits if normally displayed in your application.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1								
Command	81H	1								
Axis Number	xxH	1	Query							
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	81H	1								

Axis Number	xxH	1	0	0 = CW, 1 = CCW, 2 = Up, 3 = Down
Soft Limit	Int	2	PAN = -3600 to +3600, TILT = -1800 to +1800	
LRC	xxH	1		
ETX	03H	1		

2.8 PTCR Initial Setup Parameters:

2.8.1 Getting/Setting Pan & Tilt Potentiometer Center Position:

The pan & tilt unit uses precision potentiometers or incremental encoders to track absolute position. A 13-bit ADC converts a voltage returned from each potentiometer to a digital value, yielding a count from 0-8191. Each potentiometer should be centered as close as possible when the pan & tilt unit is at its midpoint of travel (tilt level, pan centered.) This will result in the best accuracy and reduce the chance of potentiometer damage due to over-travel. However, the controller can accommodate some misalignment.

Since the potentiometer is an absolute resolver (always returns a specific position) we must know the offset from the potentiometer reading at platform center and the ADC midpoint, 1/2 of 8192 steps or 4096. Using this value allows us to correct for a misalignment. We subtract the offset from the current reading to ascertain our position relative to 0/0.

An encoder does not return an absolute position but only indicates direction and steps. There is no absolute center. We do not need to correct the encoder reading continuously. We only need to set the encoder count to 0 when the platform is at its midpoint of travel. Therefore, an encoder-tracked axis will always return 0 as its center position when queried.

A yellow indicator for each axis will illuminate when the potentiometer reading is within 100 RU's of ADC center reading. When initially aligning the unit the potentiometer sprockets should be loosened, the pan & tilt unit should be moved to a center position using jog (with soft limit override as required), the potentiometers should be adjusted until each yellow indicator illuminates, then the sprockets should be tightened. The user should then command the PTCR to save the potentiometer center positions.

Encoders should be configured with the index pulse $\pm 10^\circ$ from physical center but only to allow the platform to easily detect and realign its readings relative to the index pulse. An encoder will also illuminate the yellow pan and tilt center readings when the count is within 100 RU's of 0/0. Since an encoder is not an absolute resolver these will have little use during alignment but will indicate the point of alignment once a unit is properly setup.

The first command will allow the user to retrieve the current stored value for potentiometer center for each axis in resolver units. A properly aligned system will return values very close to 4096 for potentiometers or 0 for encoders. The second command will allow the user to command the PTCR to read the potentiometers/encoders and save the reading as the center positions. This should be performed immediately after the potentiometers have been aligned to the platform. The result will be re-aligned returned coordinates of 0°/0° (with companion 0°/0° angle offsets.)

2.8.2 "Get Pan & Tilt Potentiometer/Encoder Center Position" Command:

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	90H	1	
LRC	xxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	90H	1	
Pan Count	Int	2	PAN = 0 – 8191(potentiometer) or 0(encoder)
Tilt Count	Int	2	TILT = 0 - 8191(potentiometer) or 0(encoder)

LRC	xxH	1
ETX	03H	1

2.8.3 “Set Pan & Tilt Potentiometer Center Position” Command:

Data	Format	Bytes	
STX	02H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	91H	1	
LRC	xxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	91H	1	
Pan Count	Int	2	PAN = 0 – 8191(potentiometer) or 0(encoder)
Tilt Count	Int	2	TILT = 0 - 8191(potentiometer) or 0(encoder)
LRC	xxH	1	
ETX	03H	1	

2.8.4 “Get/Set Pan & Tilt Ramp Parameters” Command:

These parameters determine the acceleration/deceleration rate and initial start/stop speeds for the pan and tilt axes. At the factory a minimum and a maximum step rate are set in the controller. The controller then calculates an array of interim speeds that create 255 linear steps from minimum to maximum speed. One may approximate an array speed using the following formula:

$$\text{Step Freq}[x] = (((\text{Maximum Freq} - \text{Minimum Freq}) / 254) * (x - 1)) + \text{Minimum Freq}$$

Speed[0] is always reserved for stopped. Minimum speed will be attained at Speed[1] and maximum at Speed[255].

Stepper motors require a linear speed progression (acceleration) over time to reach maximum speed without dropping “out of sync” which results in a stalled motor. However, a stepper can normally be instantaneously started at some fraction of the maximum speed without requiring acceleration. This command allows the user to define this value (Start/Stop) for pan and tilt. Starting at this value rather than absolute minimum speed will speed completion of automated moves and the accel/decel sequence. This value and the resulting frequency output will equate to “x” as shown in the formula above.

Once started, the motor will begin at the selected “safe” start speed, then accelerate as required to reach operational speed. A motor that is accelerated too quickly can also lose sync. The acceleration is performed by incrementing the array defined above by one count periodically. This value (Acc/Dec) defines the number of 50us delays to be introduced between each increment of speed. For example, an Acc/Dec value of 40 will equate to $40 * 50\mu\text{s} = 2\text{ms}$ per speed increment. If safe Start/Stop speed was set at “50” then $255 - 50$ or 205 speed increments would take place during acceleration. The platform would accelerate to full speed in $205 * 2\text{ms}$ or 410ms.

Deceleration is the mirror of acceleration. When the motor is spinning at high speed it must be decelerated in a controlled manner in order to reduce stress on the drive train. When commanded to slow the controller will decelerate the motor at the same rate as acceleration until the safe Start/Stop speed is reached. At that point the motor will be immediately stopped. Therefore, the user must consider both the units ability to start without stalling and stop without placing undo strain on the drive train when setting the Start/Stop value.

Position is of no concern when jogging the platform. However, the desired final position must be considered when performing automated moves that include deceleration. The Ramp value is used to begin deceleration for automated moves a functional distance from the final destination. The distance can be calculated by multiplying the maximum speed by the Ramp value. If the Ramp value is set for 4 and the platform has reached its maximum speed of 255 the deceleration will begin $255 * 4$ 1020 RU's away from the final destination. This value should be set by executing fairly large automated moves that allow the controller to reach full speed. If the platform

repeatedly drives past the final position, then reverses to reach it the Ramp value should be increased. If the platform consistently slows to minimum speed a significant distance from final destination the Ramp value should be decreased. The two reserved values may be written with any value between 0 and 127 but will be ignored.

Note that all values for each axis are platform, load, position, and direction dependent and must be derived by testing. It is recommended that the settings be tested when the load is moved from a position in a direction that requires the most torque from the axis. For tilt this would typically be an extreme “down” angle with a move up or vice versa. For pan this would typically be a move with the load as offset from center and unbalanced across the pan axis as possible. As a rule of thumb, if an axis immediately stalls when an automated move command is issued the Start/Stop speed is likely too high. If the axis starts but stalls at different points during acceleration the acceleration rate may be too low (accelerates too fast.) If the axis consistently overshoots the destination the ramp value rate may be too low. If the axis stalls fairly consistently at one speed it is possible the maximum step rate is too high for the load. In this case consult with the factory.

Setting the Query bit will instruct the PTCR to return the current values without changing them. Clearing the Query bit will actually load the new values into the EEPROM and update the speed parameters.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	92H	1								
P Start/Stop	xxH	1	Query	0-127						
P Acc/Dec	xxH	1	0-255							
P Ramp	xxH	1	1-15							
P Reserve	xxH	1	0	0-127						
T Start/Stop	xxH	1	0	0-127						
T Acc/Dec	xxH	1	1-255							
T Ramp	xxH	1	1-15							
T Reserve	xxH	1	0	0-127						
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	92H	1								
P Start/Stop	xxH	1	0	0-127						
P Acc/Dec	xxH	1	0-255							
P Ramp	xxH	1	1-15							
P Reserve	xxH	1	0	0-127						
T Start/Stop	xxH	1	0	0-127						
T Acc/Dec	xxH	1	0-255							
T Ramp	xxH	1	1-15							
T Reserve	xxH	1	0	0-127						
LRC	xxH	1								
ETX	03H	1								

2.8.5 “Initialize Preset Table to 0/0” Command:

This command initialize the entire preset table to 0°/0° (pan and tilt center) and set the zoom/focus bytes to 0. This can be used at initial setup to quickly clear the entire preset table. Reload the table into your application as required after issuing this command. **Actual reinitialization can take up to 3 seconds to complete before the PTCR responds.**

Data	Format	Bytes
STX	02H	1

Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	94H	1	
LRC	xxH	1	
ETX	03H	1	

Data	Format	Bytes	
ACK	06H	1	
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast
Command	94H	1	
LRC	xxH	1	
ETX	03H	1	

2.8.6 “Get/Set Motor and Potentiometer/Resolver Direction” Command:

As the controller is fitted to different QPT types, motors and resolvers will be connected through different drive systems that may require reversing readings or direction of rotation in order to make them relate properly to the platform. This command allows altering these configurations.

A device set for reverse operation is not necessarily an indication of miswiring or incorrect installation. It may simply be that the particular QPT type requires a motor or resolver to operate in the opposite direction due to design. For example, a non-continuous pan unit fitted with a potentiometer may increase its voltage output as the platform moves CW. A continuous rotation unit fitted with an encoder may actually decrease its count while moving clockwise. Both are correct. However, both will also return different directions of change when moving in the same physical direction. Configuring one unit as “Normal” and the other as “Inverted” in pan will correct this difference. A unit fitted with a higher or lower speed motor/gearbox combination may rotate the output shaft in the opposite direction. Therefore, though “Normal” mode may be the standard, this unit may operate in “Reverse” mode. Setting a bit to 0 will configure that device for "Normal" mode. Setting the bit to "1" will configure it for "Reverse/Inverse" mode. These values are set at the factory and should not normally be altered.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1								
Command	95H	1								
Pan/Tilt	xxH	1	Query	0	0	0	TRES	PRES	TMTR	PMTR
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1								
Command	95H	1								
Pan/Tilt	xxH	1	0	0	0	0	TRES	PRES	TMTR	PMTR
LRC	xxH	1								
ETX	03H	1								

2.8.7 “Get/Set Heater Configuration” Command:

Some QPT units are fitted with heaters. As the PTCR unit is normally used with low voltage DC systems the user may be limited as to the total power available for operating the unit, especially if operating from batteries. This command will allow the user to select an operating mode for the heater to match power availability as required. Option 0 will prohibit heater operation, reducing overall current draw. Option 1 and 2 will automatically cycle the heater as dictated by the on-board thermal sensor. However, in option 1 mode, a heater that is on will be turned off whenever the axis motors are operating, then be powered back on once motion has stopped. This limits instantaneous current draw. Option 2 will operate the heater as required concurrently with motor operation.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1								

Command	97H	1	Query	0 = No Heat, 1 = Share, 2 = Full Heat						
Config	xxH	1								
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	97H	1								
Config	xxH	1	0	0 = No Heat, 1 = Share, 2 = Full Heat						
LRC	xxH	1								
ETX	03H	1								

2.8.8 “Get/Set Communication Timeout” Command:

The embedded controller's sole method of operating and providing feedback is via the communication interface. Timely return of position and status information is important for many applications. However, some applications exist where feedback is of little or no use. For example, if a QPT unit is used to simply move a camera through a series of presets for viewing (a tour), constant return of positional information may not be needed. The user is only interested in the video returned by the camera. In this case, the user may wish to simply load a tour into the unit, start execution of the tour, then remove the communication connection and allow the unit to "free run." As two-wire RS-485 starts being introduced into the PTCT line it may not be possible or desired for a user's communications software to address all of the units in the communications daisy chain quickly. The capability to adjust or defeat the communication timeout value allows the user to assign a priority to the importance of constant communication.

Normally, a communication timeout is considered a fault of sufficient weight to stop any automated movement of the platform. If the data returned to the user's computer is critical, especially in determining the next move, the timeout should be set to a fairly low level (1-2 seconds.) If the user's software must share processing time and cannot service the QPT unit quickly a higher level can be set. If the user wishes the QPT to operate autonomously without the requirement for constant communication the user can set the timeout value for 0, defeating any stop due to a communication fault. Of course, all other faults will still remain active.

Setting the Query bit will instruct the PTCT to return the current value without changing it. Clearing the Query bit will actually load the new value into the EEPROM and update the fault timer.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	96H	1								
Timeout	xxH	1	Query	0(defeat) - 120 seconds						
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	96H	1								
Timeout	xxH	1	0	0(defeat) - 120 seconds						
LRC	xxH	1								
ETX	03H	1								

2.8.9 Encoder Alignment and Tracking:

As the encoders used for tracing position are incremental, not absolute, position is derived by calculating an angle from an encoder count carried in SRAM and periodically storing this count in non-volatile RAM memory. With the potentially very high update rate of the encoder at full speed (> 22000Hz) it is not possible to store every count in NVRAM during a high speed move. While the unit is powered up the SRAM values will stay accurate but, if the unit

loses power during a high speed move or is bumped when powered down, it is possible that some accuracy may be lost due to undetected, unstored transitions of the encoder.

Along with quadrature outputs, the encoders also provide an indexing pulse at one position in the unit's full rotation. Detection of this indexing pulse helps the platform update and maintain accuracy. An offset for each axis is stored in EEPROM that shows the encoder's count offset from physical center. Whenever this index pulse is crossed and detected, the PTCR will reload this offset into the encoder's count, restoring full accuracy.

This offset is initially determined using the "Initial Encoder Align" command. The user should physically align the platform by jogging to pan and tilt center (0/0). This command should then be issued. The platform will automatically move in pan, then in tilt, looking for the indexing pulses. Once found, the offsets from physical center will be calculated and the counts will be stored. In the future, whenever the index pulses are crossed during normal operations, the encoder counts will be corrected relative to the stored values.

After initial alignment and when first powered up, the platform should be within a few counts of the correct reading, depending on how the unit was handled during the power down period. As the unit is operated and the index pulse is crossed in each axis the stored count offset will be automatically loaded, increasing the reading to full accuracy. Optionally, the user may also force a realignment to the index pulse by executing a "Perform Homing Cycle" command. The platform will automatically move to the area where the index pulse is expected to occur, will update the count, then return to the corrected original position.

2.8.10 "Initial Encoder Align" Command:

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9DH	1								
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9DH	1								
Pan Index	Int	2	0 – 30000							
Tilt Index	Int	2	0 – 30000							
LRC	xxH	1								
ETX	03H	1								

2.8.11 "Perform Homing Cycle" Command:

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9EH	1								
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9EH	1								
Pan Offset	Int	2	0 – 30000							
Tilt Offset	Int	2	0 – 30000							
LRC	xxH	1								
ETX	03H	1								

2.8.12 “Get/Set Identity Address” Command:

The identity address is used to uniquely identify a unit in a daisy-chained RS-485 environment. When the identity address is sent only the unit with a matching identity address will parse the incoming data, execute the command, seize the host receive line, respond, then release the line. The absence of responses from the other units allows a clear path for data return on the receive data line.

This command can be used to initially set or change the unit’s identity address. If the user knows the current address of the unit to modify the current address should be sent as the Identity with the new address sent as the New Identity data byte. The unit will respond with the current address as the Identity and the new address as the New Identity response byte. **From this point forward the unit’s identity address has been changed and it will only respond to the new address.**

What if the user loses the identity address of a unit? It can still be retrieved or changed by sending the 00 “broadcast” as the identity address. Any command will result in the return of the current identity in the response. Note, however, that any and all units in the network will act upon and respond to a broadcast command.

Therefore, the unit to modify must be isolated from the other units by either disconnecting the other units from the daisy chain or by connecting the unit to modify directly to a dedicated host.

When operating in a dedicated RS-232 or RS-422 mode the identity should be set for 00. This will cause the dedicated unit to seize and hold the host’s receive line full time.

Data	Format	Bytes	7	6	5	4	3	2	1	0
STX	02H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9FH	1								
New Identity	xxH	1	Query	1-99 (01H-63H) for RS-485 identity or 00 for dedicated						
LRC	xxH	1								
ETX	03H	1								

Data	Format	Bytes	7	6	5	4	3	2	1	0
ACK	06H	1								
Identity	xxH	1	1-99 (01H-63H) for RS-485 identity or 00 for dedicated/broadcast							
Command	9FH	1								
New Identity	xxH	1	0	New Identity = 00-99 (00H-63H)						
LRC	xxH	1								
ETX	03H	1								

3. Code Examples

The following snippets from the PTCR microcontroller code provide some examples of how to implement efficient communications with the PTCR. Though the code is specifically written for a microcontroller compiler the unfamiliar commands should be self-explanatory. The snippets include LRC calculation and ESC/Bit-7 Set handling. Both transmit and receive procedures are interrupt based in these examples. **Note that, for the host's end, the handling of STX and ACK should be reversed.**

```
// Serial Communications Constants
#define STX      0x02
#define ETX      0x03
#define ACK      0x06
#define NAK      0x15
#define ESC      0x1B

// Serial Transmit Interrupt Triggered on TX Buffer Empty
#include <int_tbe>
tbe_isr() {
    if( tx_ptr == tx_len ) {
        putc( ETX );                // send ETX and
        disable_interrupts(INT_TBE); // buffer empty so disable transmit
    }
    else {
        switch( tx_buff[tx_ptr] ) { // if a control character
            case STX :
            case ETX :
            case ESC :
            case ACK :
            case NAK : putchar( ESC ); // send and escape
                       bit_set( tx_buff[tx_ptr], 7 ); // and set bit 7 of data byte
                       break;
            default  : putchar( tx_buff[tx_ptr] ); // else just handle normally
                       tx_ptr++;
                       break;
        }
    }
}

// Serial Receive Interrupt
// Reception of an ETX must also follow setting an "STX found" flag so we
// will not try to parse a partial reception of data.
#include <int_rda>
rda_isr() {
    int temp_rx;
    temp_rx = getc(); // get character from serial port
    switch( temp_rx ) {
        case STX : rx_ptr = 0; // realign to front of buffer
                   rx_done = FALSE; // new stream coming, last corrupt
                   esc_flag = FALSE; // clear possible escape flag
                   found_id = FALSE; // clear identity found flag
                   found_stx = TRUE; // and indicate an STX was found
                   break;
        case ETX : if( found_stx ) { // if we started with an STX
                     rx_done = TRUE; // flag done
                     found_stx = FALSE; // clear to find another STX
                 }
                 found_id = FALSE; // clear to find another identity
    }
}
```

```

        esc_flag = FALSE;          // and clear possible escape flag
        break;
    case ESC : esc_flag = TRUE;      // escape found so flag
        break;
    default  : if( esc_flag ) {      // if last char was an escape
        bit_clear( temp_rx, 7 );    // clear bit 7
        esc_flag = FALSE;          // and clear flag
    }
    if(( found_STX ) && (!found_id)) { next byte must be ID
        rx_id = temp_rx;
        found_id = TRUE;
    }
    else {
        rx_buff[ rx_ptr ] = temp_rx; // save byte
        if( rx_ptr == 50 )           // prevents buffer overrun
            rx_ptr = 0;
        else
            rx_ptr++;                // and increment pointer
    }
    break;
}
}

// Calculates and returns transmit LRC
// length is actually number of bytes, not top subscript
int Calc_LRC( int length ) {
    int temp_LRC = 0, index;
    for( index = 0; index < length; index++ )
        temp_LRC ^= tx_buff[index];
    return( temp_LRC );
}

// Calculates and returns TRUE if LRC was good or FALSE if LRC failed
short Check_LRC(void) {
    int temp_LRC, index;
    temp_LRC = rx_id;                // prime with receive identity
    for( index = 0; index < rx_ptr; index++ )
        temp_LRC ^= rx_buff[index];
    return( temp_lrc == 0 );
}

// Send data
void send_data( int cmd_num ) {
    tx_buff[0] = unit_id;
    tx_buff[1] = cmd_num;
    tx_buff[2] = somedata;
    tx_buff[3] = moredata;
    tx_buff[4] = Calc_LRC( 4 );
    tx_len = 5;
    tx_ptr = 0;
    putchar(ACK);
    enable_interrupts(INT_TBE);      // triggers on TX buffer empty
}

void main( void ) {

    disable_interrupts(INT_TBE);
    enable_interrupts(INT_RDA);

```

< Code >

```
if( rx_done ) {                                // if we have received a packet
    rx_done = FALSE;                            // reset for next packet whether good or bad
    if( Check_LRC() ) {                        // check the received LRC
        process_data;                          // if good, process the data
        act_on_data;
        gather_return_data;
        send_data( echo_command );            // and send the response
    }
}
```

4. Revision History:

4.1 Rev A 07/08/05

Initial Release

4.2 Rev B 02/23/06

Change in accel/decel algorithm. See command 92H.

© QuickSet International, Inc.

MN00087 3/23/2006

